



# USB 2.0 Gigabit Network Adapter Model # AGIGAUSB User's Manual

Ver. 1A

# **Table of Contents**

Introduction	4
Package Contents	
Specifications	
Network Specification	
Host Interface	
Supported operating systems	4
LED Indicators	
Power Requirement	5
EMC Certification	
Installation	6
Verify Driver Installation	12
Technical Support	

# REGULATORY STATEMENTS FCC Certification Part15, Class B

The United States Federal Communication Commission (FCC) and the Canadian Department of Communications have established certain rules governing the use of electronic equipment.

### **FCC Part 15 Registration**

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interface, and
- This device must accept any interface received, including interface that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

# Introduction

The **USB 2.0 Gigabit Network Adapter** (hereafter referred to as the Gigabit Adapter) is specifically designed to plug into any available Universal Serial Bus port of a desktop or laptop PC. The Gigabit Adapter is for users who wish to connect to a 10Mbps, 100Mbps or 1000Mbps Fast Ethernet LAN using the convenience and ease of USB technology.

The Gigabit Adapter complies with USB Specification 1.0/1.1/2.0. It uses an USB type B connector to connect directly to the USB host computer and a RJ-45 connector provides a quick and simple method of connecting to an Ethernet or Fast Ethernet network.

This low power-consuming device draws power from the host USB bus directly, so no external power supply is required. Simply connect the USB port of this device to the computer and plug a standard twisted-pair Ethernet cable into the RJ-45 port, and you'll be networked in no time. This device offers a simple way to connect to your network.

# Package Contents

- Gigabit Network Adapter
- USB 2.0 Cable
- Driver CD
- Quick Installation Guide

# Specifications

# **Network Specification**

- IEEE802.3 10BaseT, 802.3u 100BaseTX and 802.3ab 1000Base-T.
- Cat3/Cat5 UTP cable up to 328ft/100M.

### **Host Interface**

- High-power Bus-powered from USB HOST or HUB, no external power needed.
- Full Speed/High Speed USB device, upstream B USB port.

# **Supported operating systems**

Windows 2000/XP

### **LED Indicators**

- Link: When the device is well-connected to the computer, the Link LED will appear as solid green.
- TX/RX: 10/100/Ğigabit linking status

**10Mbps:** Appears as solid orange + green when the device is connected to 10Mbps network; blinking orange + green when transmitting data.

**100Mbps:** Appears as solid orange when the device is connected to 100Mbps network; blinking orange when transmitting data.

**Gigabit:** Appears as solid green, when the device is connected to Gigabit network; blinking green when transmitting data.

# **Power Requirement**

Operating Voltage: 5V DC Operation Mode: 425mA (Max)

Physical specification

Dimension: 3.2"(L) x 2.2"(W) x1" (H)

### **EMC Certification**

- FCC Part15 ClassB
- CE
- VCCI

## Installation

The following steps and screen shots are for Windows XP. Steps for Windows 2000 are similar unless noted otherwise.

**Note: Do not** connect the USB 2.0 Gigabit Network Adapter to your computer until you've reached the appointed step. If the Gigabit Adapter is connected already, Windows will detect the Adapter and request for a driver. Click **Cancel** to quit the wizard and remove the Gigabit Adapter from your computer.


**Step 1** Insert the Driver CD into your CD drive and wait for the autorun window to appear on screen.

Step 2 Click on Install Driver at the autorun window.


**Note:** If the autorun window doesn't appear automatically go to **Start**, **Run**, and type **D:\autorun.exe** (where **D** is the letter of your CD drive) and click **OK**.




Step 3 Click Next at the welcome screen.



**Step 4** Click **Next** to accept the default destination location for the driver to be installed in or click **Browse** to select the desired location.



Step 5 Click Next to accept the Program Folder for the driver.



**Step 6** Click **Continue Anyway** at the Windows Logo Testing prompt. (For Windows 2000, click **Yes** at the Digital Signature Not Found prompt).




**Step 7** Click **Finish** to complete the installation wizard.




**Step 8** Connect one end of the Gigabit Network Adapter to your computer's USB port and connect the other end to a hub/switch/router.

**Step 9** At the **Found New Hardware Wizard** window, select **No, not this time** and click **Next**.



Step 10 Select Install the software automatically (Recommended) and click Next.




For Windows 2000, select **Search for a suitable driver for my device** (**Recommended**) and click **Next**. Then check on the **CD-ROM drives** check box and click **Next**.

**Step 11** Click **Continue Anyway** at the Windows Logo Testing prompt. (For Windows 2000, click **Yes** at the Digital Signature Not Found prompt).



**Step 12** Click **Finish** to complete the installation.




Step 13 Restart your computer to activate the Gigabit Network Adapter.

# **Verify Driver Installation**


To verify if the driver has been installed successfully, please perform the following steps.

Step 1 Right-click on My Computer from your desktop and select Properties.

**Step 2** Select the **Hardware** tab and click on **Device Manager**.



**Step 3** Expand **Network adapters** from the list and verify that **10/100 Gigabit USB2.0 Network Adapter** is listed and no yellow question mark is beside it.



Congratulations! You have successfully installed the USB 2.0 Gigabit Network Adapter.

# **Technical Support**

E-mail: support@airlink101.com

Toll Free: 1-888-746-3238

Web Site: www.airlink101.com

Copyright © 2005 AirLink101. All rights reserved. AirLink101, the stylized AirLink101 logo, specific product designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of AirLink101. All other product or service names are the property of their respective holders. AirLink101 products are protected under numerous U.S. and foreign patents and pending applications, mask work rights, and copyrights.

<sup>\*</sup>Actual throughput will vary. Network conditions and environmental factors lower actual throughput rate.