

BATTERY DRIVE, MICRO LINE THERMAL PRINTER 2" TYPE MECHANISM AND INTERFACE BOARD

FTP-623MCL400/FTP-623DCL002

OVERVIEW

This battery driven, micro line thermal printer provides high speed printing for 2-inch wide (58mm) paper. It is suitable for portable equipment that requires compact, light weight components.

In addition to the interface board, a driving LSI (MCU + Gate Array) is also available.

■ HIGHLIGHTS

• Driven by batteries (direct connect between thermal head and batteries)

It can be driven by a broad range of voltages (4.2 to 8.5 V) of NiCd or Nickel-Hydrogen by using Fujitsu Components' unique head drive control system. The battery pack can be connected directly to the print head without a voltage regulator. Also, a lithium-ion battery can be used.

· High speed printing

It can print at approximately 23 character lines/s (460 dotlines/s = 57.5 mm/s).

· Compact and lightweight

It has a light weight of approximately 75 g.

Low power consumption

The peak current for head driving is approximately 3.0 A.

Selectable paper paths

Front, rear, and top paper insertion paths can be used.

Paper auto loading function


Paper feeding is enabled by operating the head up lever.

Variety of suitable papers


This model is suitable for printing on a variety of papers, including 1-ply roll paper, 2-ply paper (TCC and roll), labels, and long-life paper.



FTP-623MCL400



FTP-623CU001, FTP-633GA101



FTP-623DCL002

■ DESIGNATION

	Item	Part number
Printer mechanism		FTP-623MCL400 *
Interface board		FTP-623DCL002
1.01	Micro Controller Unit	FTP-623CU001
LSI	Gate Array	FTP-633GA101

^{*:} Rear paper insertion type is available: FTP-623MCL402

■ GENERAL SPECIFICATIONS

Item	Specifications
Printing method	Thermal-sensitive line dot method
Dot structure	384 dots/line
Dot pitch (Horizontal)	0.125 mm (8 dots/mm)—Dot density
Dot pitch (Vertical)	0.125 mm (8 dots/mm)—Line feed pitch
Effective printing area	48 mm
Printing mode	(1) Single density — Standard mode — HS mode 1. to 3. HQ mode Reduced mode — HS mode 1. to 3. HQ mode (2) Double density mode
Maximum printing speed	Approximately 23 character lines/s (460 dotlines/s = 57.5 mm/s) [1ply, 8 columns of "H", double density, 7.2 V, 1/10" line returns] Approximately 16 character lines/s (416 dotlines/s = 52 mm/s) [1ply, 12 columns of "H", double density, 7.2 V, 1/8" line returns]
Character types	JIS ANK : 128 ASCII : 31 Semi-graphic : 36 International characters : 130 Special : 30 Download : 8
Character grade mode	Standard character (12 \times 6 dot font)/High grade character (16 \times 8 dot font)
Character composition, dimensions (H×W), Number of columns (standard)	Single density standard : 24×12 dots, $(3.0 \times 1.5$ mm), 32 columns 32×16 dots, $(4.0 \times 2.0$ mm), 24 columns Single density reduced*1 : 24×12 dots, $(3.0 \times 1.5$ mm), 34 columns 32×16 dots, $(4.0 \times 2.0$ mm), 26 columns Double density : 16×8 dots, $(2.0 \times 1.0$ mm), 48 columns
Interface	1) Centronics standard 2) Bus interface*2

(Continued)

(Continued)

	Item	Specifications				
	For print head	4.2 to 8.5 VDC (4 or 5 Ni-Cd or Ni-MH batteries, equivalent to 2 Li-ion) Approximately 3.0 A (peak value, 7.2 V, 100% printing ratio)				
Operating voltage	For motor	4.2 to 8.5 VDC (4 or 5 Ni-Cd or Ni-MH batteries, equivalent to 2 Li-ion) Average 0.7 A or less				
	For logic	5 VDC ± 5%, 0.15 A				
Weight		Mechanism: approximately 75 g. Interface board: approximately 60 g				
Printer mechanism	Dimensions	73 (W) \times 49 (D) \times 20 (H) mm (excluding knob, lever, and flexible PC board)				
Interface board	Dimensions	108 (W) × 91 (D) × 18 (H) mm				
Thermal head life		Pulse durability: 1 × 10 ⁸ pulse/dot (using Fujitsu Takamisawa's standard driving method) Wear resistance: 50 km (at 25% printing ratio)				
	Operating temperature	+5 to +40°C*3				
Environmental conditions	Operating humidity	20 to 85% RH (no condensation)				
	Storage temperature	-20 to +60°C (excluding paper)				
	Storage humidity	5 to 95% RH (no condensation)				
	Head temperature	By thermistor				
Detection	Paper out/Mark detect	By photointerrupter (command set)				
	Voltage	By micro controller				
	Head-up	By microswitch				
Paper width		58 ⁺⁰ ₋₁ mm				
Recommended thermal sensitive paper		1 ply (roll) : FTP-020PG021 Long life (roll) : FTP-020PR202 Label (roll) : FTP-040PL021 2 ply (TCC) : FTP-020P8820 2 ply (roll) : FTP-020P7121				


^{*1:} Character composition for single density reduced mode is the same as for single density standard mode.


^{*2:} The data to be printed is automatically read out by the printer driver equipment memory (host system frame memory). The communication is parameter transfer.

^{*3:} Temperature range for guaranteed printing density. It can be operated in the range of 0 to +40°C.


■ DIMENSIONS

Printer mechanism





Interface board



■ INTERFACE

1. Centronics standard

(1) Connector

Connector part number : FCN-215Q030-G/0 (Fujitsu Components) or equivalent Mating connector part number : FCN-217Q030-G/0 (Fujitsu Components) or equivalent FCN-214Q030-G/0 (Fujitsu Components) or equivalent

FCN-215Q030-G/0 (Fujitsu Components) or equivalent


(2) Connector pin assignment

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	PRSTB	I	Data strobe	2	PRSTB-RET	_	Connected to logic GND
3	PRDT0	I	Data 0	4	PRDT0-RET	_	Connected to logic GND
5	PRDT1	I	Data 1	6	PRDT1-RET	_	Connected to logic GND
7	PRDT2	I	Data 2	8	PRDT2-RET	_	Connected to logic GND
9	PRDT3	I	Data 3	10	PRDT3-RET	_	Connected to logic GND
11	PRDT4	I	Data 4	12	PRDT4-RET	_	Connected to logic GND
13	PRDT5	I	Data 5	14	PRDT5-RET	_	Connected to logic GND
15	PRDT6	I	Data 6	16	PRDT6-RET	_	Connected to logic GND
17	PRDT7	I	Data 7	18	PRDT7-RET	_	Connected to logic GND
19	ACKNLG	0	Data input acknowledge	20	ACKNLG-RET	_	Connected to logic GND
21	BUSY	0	Busy	22	BUSY-RET	_	Connected to logic GND
23	RINF2	0	Printer status	24	INPRM-RET	_	Connected to logic GND
25	SLCTIN	I	Printer select	26	INPRM	I	Reset
27	RINF1	0	Printer status	28	RINF3	0	Printer status
29	ĀTF	I	Paper feed request	30	GND	_	Logic GND


Notes:

- Symbol "---" means a negative logic signal.
- "-RET" signal is a return signal of the twisted pair cable.
- "I" or "O" means a signal direction from the interface board side.

(3) Connector pin number



(4) Data input signal timing



2. Bus interface

(1) Connector

Connector part number : FCN-215Q040-G/0 (Fujitsu Components) or equivalent Mating connector part number : FCN-217J040-G/0 (Fujitsu Components) or equivalent

: FCN-214J040-G/0 (Fujitsu Components) or equivalent : FCN-215J040-G/0 (Fujitsu Components) or equivalent

(2) Connector pin assignment

` '	F								
No.	Signal	I/O	Contents	No.	Signal	I/O	Contents		
1	ALE	0	Address latch	2	BRD	_	Data read		
3	BWR	_	Data write	4	READY	_	Data access ready		
5	HACK	_	Hold acknowledge	6	HRQ	_	User hold request input		
7	MCRC	_	Power-down (not used)	8	CLK	0	System clock		
9	PCPAK1	0	Common RAM reading completion	10	ATF	ı	Automatic paper loading		
11	PCPSD1	ı	Common RAM reading request	12	PRON	0	Printer operating		
13	RST	I	Hard reset	14	GND	_	Ground		
15	DB00	I/O	External address/Data bus 0	16	DB01	I/O	External address/Data bus 1		
17	DB02	I/O	External address/Data bus 2	18	DB03	I/O	External address/Data bus 3		
19	DB04	I/O	External address/Data bus 4	20	DB05	I/O	External address/Data bus 5		
21	DB06	I/O	External address/Data bus 6	22	DB07	I/O	External address/Data bus 7		
23	AB08	0	External address bus 08	24	AB09	0	External address bus 09		
25	AB10	0	External address bus 10	26	AB11	0	External address bus 11		
27	AB12	0	External address bus 12	28	AB13	0	External address bus 13		
29	AB14	0	External address bus 14	30	AB15	0	External address bus 15		
31	AB16	0	External address bus 16	32	AB17	0	External address bus 17		
33	AB18	0	External address bus 18	34	AB19	0	External address bus 19		
35	AB20	0	External address bus 20	36	AB21	0	External address bus 21		
37	AB22	0	External address bus 22	38	AB23	0	External address bus 23		
39	RAM2	0	Common RAM access	40	INPRM	I	Reset		

Notes:

- Symbol "—" means a negative logical signal.
- "I" or "O" meas a signal direction from the interface board side.

■ CONNECTOR PIN ASSIGNMENT

1. Connector for logic power supply (CN1)

Part number : B4B-XH-A-WHITE (J.S.T) or equivalent \rightarrow P.C.B side

Mating connector part number : XHP-4 (J.S.T) or equivalent \rightarrow Cable side

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	Vcc	_	Power supply for logic (+5V)	2	GND	_	Logic ground

2. Connector for thermal head and motor power supply (CN2)

Part number : B6B-XH-A-WHITE (J.S.T) or equivalent \rightarrow P.C.B side

Mating connector part number : XHP-6 (J.S.T) or equivalent \rightarrow Cable side

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	BAT	_	Power supply for head/motor	2	BAT	_	Power supply for head/motor
3	BAT	_	Power supply for head/motor	4	GND	_	Head/motor ground
5	GND	_	Head/motor ground	6	GND	_	Head/motor ground

3. Connector for thermal head drive (CN7)

Part number : 52030-2610 (Molex) or equivalent \rightarrow P.C.B side

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	BAT	_	Power for head	2	BAT	_	Power for head
3	GND	_	Head ground	4	GND	_	Head ground
5	HD2	0	Print data output	6	LAT	0	Printing data latch
7	HDV	0	Power for logic	8	HCLK	0	Printing transmitting clock
9	ENB8 *1, 2	0	Printing enable (not used)	10	ENB7 *1,2	_	Printing enable (not used)
11	ENB6	0	Printing enable	12	ENB5	0	Printing enable
13	VREF	0	Power for thermistor	14	TMP	0	Temperature detection
15	*3	_	Connected with No. 17	16	HDV	0	Power for logic
17	*3	_	Connected with No. 15	18	*4	_	Head rank specify (not used)
19	*4	_	Not used (pulled-up by resistor)	20	ENB4	0	Printing enable
21	ENB3	0	Automatic paper loading	22	ENB2	0	Printing enable
23	ENB1	0	Printing enable	24	GND	_	Paper-out detection
25	GND	_	Printing enable	26	BAT	_	Power for head

Notes:

- *1: Mechanism selection signal and the printing enable signal for 3" mechanism.
- *2: Not used at the combination with 2" mechanism.
- *3: At the mechanism side, this pin number is for the printing data 2.

 Since this pin number is used for the printing data 1 at the interface board, the No. 15 and No. 17 pins are connected.
- *4: This signal is used for the adjustment of printing duty depending upon the rank of thermal head resistor. Not used at this interface board.
 - Symbol "——" means a negative logic signal.
 - "I" or "O" means a signal direction from the interface board side.

4. Connector for abnormal head temperature detection (CN6)

Part number : B3B-XH-A-WHITE (J.S.T) or equivalent \rightarrow P.C.B side

Mating connector part number : XHP-3 (J.S.T) or equivalent \rightarrow Cable side

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	TMPER	0	Abnormal head temperature detection	2	N.C.	_	Not connected
3	GND	_	Logic ground				

Note: This signal detects abnormal head temperature.

5. Connector for stepping motor drive (CN8)

Part number : B10B-ZR (J.S.T) or equivalent \rightarrow P.C.B side

Mating connector part number : $ZHR-10 (J.S.T) \rightarrow Mechanism side$

No.	Signal	I/O	Contents	No.	Signal	I/O	Contents
1	HUP	I	Head up detection	2	Vcc	_	Power for switch
3	PINCH	I	Paper auto loading detection	4	SDV	_	Power for photointerrupter
5	SLED		Power for diode cathode	6	PES	ı	Paper out detection
7	MT/B0	0	Stepping motor coil excitation (B)	8	MT/B0	0	Stepping motor coil excitation (B)
9	MT/A0	0	Stepping motor coil excitation (A)	10	MT/A0	0	Stepping motor coil excitation (A)

■ PRINTING COMMANDS (CENTRONICS STANDARD INTERFACE)

Name	Command	Contents
Carriage return	LF, CR	Prints buffer data and returns the line.
Double width print set	SO	Sets the double width character.
Power-down mode set	DC2, DC3	Reduces power consumption during stand by.
Double width print reset	DC4	Resets the double width character.
ESC sequence entry	ESC	Indicates the start of an escape sequence formed by this code plus subsequent commands.
Line space set	ESC A + n	Sets the line space length in 2 \times (0 to 255 dot lines).
Paper feed set in normal direction	ESCB+n	Sets the paper feed in normal direction. (Feeding range: $2 \times (0 \text{ to } 255 \text{ dot lines}))$
Bit image print set	ESC K +n1+n2+n3	Sets the bit image printing in single or double density mode.
International character set	ESC R+n	Selects the international characters.
Download character register	ESC &+n1+n2+~	Registers the download characters of 12 \times 6 or 16 \times 8 dots.
Printing quality set	ESC Q+n+SP*+~	Sets the printing quality conforming to selected paper.
Printing density set	ESC Q+n+!+A	Sets the printing density mode. (Single density standard, reduced, or double density)
Paper feed set in reverse direction	ESC j+n	Sets the paper feed in reverse direction. (Feeding range: 2 × (1 to 255 dot lines))
Character grade set	ESC x+n	Sets the character grade in standard or high grade.
Special character print set	ESC ¥+n	Prints special characters.
Start position set for bit-image printing	ESC 1+n	Sets the print start position of bit-image printing at the left end.
Detecting function set	ESC 9+n	Sets the detecting function.
Mark detection	ESC FF	Feeds the paper to the marking position.
Line feed length set after mark detection	ESC w+n	Sets the line feed length after mark detection.
Automatic paper loading length set	ESC EM+n	Sets paper feeding length for automatic paper loading.
Automatic printing speed set	ESC s+n	Sets the function mode in the automatic printing speed set.
Printer initialization	ESC @	Initializes the printer MPU.

Notes:

^{*: &}quot;SP" means the space code (20H).

Bus interface uses different commands.

■ OPTIONS

1. Cable

1	Name	Part number	Cable length	
Interface cable	For Centronics	FTP-621Y202	500 mm	
	For Bus I/F	FTP-621Y203	500 mm	
Power supply cable (A):	for logic motor	FTP-621Y401	300 mm	
Power supply cable (B):	Power supply cable (B): for thermal head		300 mm	
Head abnormal tempera	ture detection cable	FTP-621Y204	300 mm	

Fujitsu Components International Headquarter Offices

Japan

Fujitsu Component Limited Gotanda-Chuo Building

3-5, Higashigotanda 2-chome, Shinagawa-ku

Tokyo 141, Japan Tel: (81-3) 5449-7010 Fax: (81-3) 5449-2626

Email: promothq@ft.ed.fujitsu.com

Web: www.fcl.fujitsu.com

North and South America

Fujitsu Components America, Inc. 250 E. Caribbean Drive Sunnyvale, CA 94089 U.S.A. Tel: (1-408) 745-4900 Fax: (1-408) 745-4970

Email: marcom@fcai.fujitsu.com Web: www.fcai.fujitsu.com

Fujitsu Components Europe B.V.

Diamantlaan 25 2132 WV Hoofddorp Netherlands

Tel: (31-23) 5560910 Fax: (31-23) 5560950

Email: info.marketing@fceu.fujitsu.com

Web: www.fceu.fujitsu.com

Asia Pacific

Fujitsu Components Asia Ltd. 102E Pasir Panjang Road #04-01 Citilink Warehouse Complex

Singapore 118529 Tel: (65) 375-8560 Fax: (65) 273-3021 Email: fcal@fcal.fujitsu.com www.fcal.fujitsu.com

© 2001 Fujitsu Components America, Inc. All company and product names are trademarks or registered trademarks of their respective owners. Rev. 09/2001