

Biobrick Resuspension

Materials and Equipment

- Micropipette
- Micropipette tips

Reagents

- Nuclease free water
- iGEM Plates

Methodology

1. Localize the interest well and mark it .
2. Using a micropipette tip, perforate the well.
3. Add 10 μ L of H₂O.
4. Resuspend and let the plate rest for 5 minutes.
5. Store the plate at -20°C.